



Inner circle indicates color of leadwire

Outer circle indicates color of leadwire plug and jacket, and also color of socket on MINI-Q device

Numbers indicate MINI-Q Switch Positions

Note: A1 and A2 leadwire colors may differ depending on sensor type

Note: Electrode set may include "spare" sensor with white lead / black plug

Electrode Locations & Switch Positions for MINI-Q **(with Leadwire Color Codes)**

(Same color codes as ElectroCap E1-LEX "Lexicor" type cap)

For use with standard sensor sets or with
FlexCap 10-20 MINI-Q Head Gear Package
621-041 or 621-042